

Rev. A


## **Description**

**DALI-PROGRAM** is the programmer for DALI Inventronics drivers.



#### **Model**

Name	Description	P/N	
Programmer	Programmer for LED Driver	DALI-PROGRAM	



**Interface Specifications** 

Parameter	Min.	Тур.	Max.	Notes
DA1 High Level	10 V	17 V	20 V	
DA2 Low Level	-1 V	0 V	1 V	
DA1, DA2 Current	0 mA	-	6 mA	

**Environmental Specifications** 

Parameter	Min.	Тур.	Max.	Notes
Operating Ambient Temperature	-20 ℃	-	+50 ℃	Humidity: 10%RH to 90%RH. No condensation.
Storage Temperature	-40 °C	-	+70 °C	Humidity: 5%RH to 90%RH. No condensation.

**General Specifications** 

Parameter	Min.	Тур.	Max.	Notes
Dimensions (L × W × H) Inches Millimeters	3.35 × 1.85 × 0.83 85 × 47 × 21			
Net Weight	-	40 g	-	

**Note:** All specifications are typical at 25 °C unless otherwise stated.

1/5

Fax: 86-571-86601139

Specifications are subject to changes without notice.



Rev. A

**Packing List** 

Packing List	Function		
DALI-PROGRAM	Programmer		
USB wire	Connect PC and Programmer		


## **Programming Interface Software**

From the following website, download and follow the Installation Instructions for Programming Interfaces: http://www.inventronics-co.com/download.aspx?c kind2=17&c kind3=154

The installed software automatically checks for updates over the internet.

#### **Connections**

• The programming system connection is shown as below.




Note: The driver needs to be powered on during the programming process

Pin	Connection	Pin	Connection
DA1	To LED driver's DA1 output wires	USB	To PC
DA2	To LED driver's DA2 output wires		

#### **PC** Interface

Take the LUD-060 Series for example; the following is the PC interface implementation of LUD-060S150BSF:



2/5

Fax: 86-571-86601139

Specifications are subject to changes without notice.



Rev. A

Introduction of the functions in the software interface:


Item	Name	Description			
1	Exit	Exit the PC Interface			
2	中文	Turn into Chinese Version			
3	Basic OP	Basic Operation PC Interface			
4	On	Turn on the driver			
5	Off	Turn off the driver			
6	Linear Curve	To click "linear curve", the dimming curve will be set to Linear Dimming Curve			
7	Logari Curve	To click "Logarithmic Curve", the dimming curve will be set to Logarithmic Dimming Curve			
8	Down	Dimming Down			
9	Up	Dimming Up			
10	Output Power	To set the current value by sliding it			
11	Fade Time	To set the fade time; longer the fade time, slower the change speed			
12	Driver Set	To set the information related to the LED Driver			
13	Select LED Driver	To choose the series and the model, which need to be programmed			
14	Max Current	To set the max output current of the driver			
15	OLC	To choose whether the OLC is needed or not			
16	OTP Setting	To set the current after OTP occurred (the triggered point and the recovery point are decided by the thermistor and the customer's requirements)			
17	Read Cfg	To read the configuration file, which has been set			
18	Save Cfg	To save the configuration file, which has been set			
19	Read Drv	To read the configuration of the LED Driver			
20	Write Drv	To write the configuration into the LED Driver			

Fax: 86-571-86601139



Rev. A

## **Mechanical Outline**



# **RoHS Compliance**

Our products comply with the European Directive 2011/65/EC, calling for the elimination of lead and other hazardous substances from electronic products.



Rev. A

Programmer for LED Drivers with DALI

# **Revision History**

Change Date	Rev.	Description	Description of Change			
Date	rev.	Item	From	То		
2014-07-28	Α	Datasheets Release	/	/		